

## RESET SHUT OFF N.O. GAS SOLENOID VALVES

### GARO ...

#### APPLICATION

- Used in conjunction with safety systems, for gas feed pipe shutoff
- The valves can only be opened manually, stay open only when powered is cut, and only close when powered up.

#### Features

#### TECHNICAL DATA

- Power supply 230 V~, 24 V~, 12 V-
- Voltage tolerance – 15%...+10%
- Power absorbed in Watts : see table
- Max. operating power : see table
- Protection IP 65
- Construction : brass body

Code	DN	Power supply		P.max <sup>(1)</sup> mbar	Flow rate m <sup>3</sup> /h <sup>(2)</sup>		Data Sheet
		V	W		0.5 mbar	1 mbar	
<b>GARO 815</b>	1/2"	230 V AC	7	500	1,8	2,6	G 934
<b>GARO 415</b>	1/2"	24 V AC	4	500	1,8	2,6	G 934
<b>GARO 215</b>	1/2"	12 V DC	6	500	1,8	2,6	G 934
<b>GARO 820</b>	3/4"	230 V AC	7	500	3	4,5	G 934
<b>GARO 420</b>	3/4"	24 V AC	4	500	3	4,5	G 934
<b>GARO 220</b>	3/4"	12 V DC	6	500	3	4,5	G 934
<b>GARO 825</b>	1"	230 V AC	8	500	4,5	6,6	G 934
<b>GARO 425</b>	1"	24 V AC	22	500	4,5	6,6	G 934
<b>GARO 225</b>	1"	12 V DC	8	500	4,5	6,6	G 934

(1) – Maximum working pressure 100 mbar = 10 kPa = 1,000 mmWG

(2) – Natural gas flow with pressure drop of 0.5 mbar (5mmWG) and 1 mbar (10 mmWG)